





# We-Vibe® Sync™ Custom Fit

Two spots that adjust



Your Sync can be adjusted for a custom fit.  
Find the fit that's right for you and then enjoy.

By making small adjustments to the position of either clitoral or G-spot stimulator, you can apply more or less pressure where you need it. Avoid twisting your Sync or bending it rapidly or repeatedly.



Respect the original shape of your Sync. With small adjustments, you can fine-tune the fit to make it perfect for you. Distorting Sync's shape by bending it too far may damage it. Treat your Sync like you'd treat your partner: gentle but firm. Try these positions:

